CABINET PARTS

For Models: 3XARG477GF00
(White)

REFRIGERATOR



1		Cabinet (Not A Serviceable Part)
2	2157591	Hinge (Top)
3	2166108	Roller-Front (2)
4	489426	Screw
5	489385	Clamp, Tube (Water Supply Line)
6	489497	Screw
7	2174650	Screw
8	2172743	Shim, Bottom Hinge
9	1129332	Cord-Service
10	2158579	Enclosure, Terminal Block
11	1129346	Terminal Block
13	1129449	Bushing
14	489211	Screw
15	489423	Screw
16	2183972	Hinge, Center
17	2183854	Shim, Hinge Center
18	489464	Screw
19	489399	Screw
20	2189194	Hinge Butt
21	2166651	Wire Assembly
22	2167227	Gasket
24		Fitting, Water Tube (NOT SERVICED)
25	2151652	Hole Plug (6)
26	2166251	Cover, Valve
27	2163733	Corner Filler (2)
28	2189157	Grille
29	489341	Washer, Plain
30	487576	Washer, Nylon
31	2160403	Cover-Hinge
32		Rail, Center (NOT SERVICED)
33	2166156	Corner Filler, Grille
34	2189059	Cover, Unit

LINER PARTS

For Models: 3XARG477GF00

(White)



1		Liner (Not A Serviceable Part)
2	531933	Grommet (2)
3	2189268	Gasket, Evaporator Cover (Side)
4	2166867	Timer, Defrost
5	549512	Thermostat Tube Barrier
6	940014	Hole Plug
7	2193492	Wire Assy. Control Box
8	2162085	Socket, Light (2)
9	2179858	Damper, Air
10	2183828	Fan Motor
11	2163777	Fan Blade
12	2179790	Control Box
13	2193307	Thermostat Assembly (Includes Items 5, 18, & 36)
14	2176341	Clip, Defrost Timer
15	489412	Screw
16	2183152	Cover-Evaporator
18	2163802	Weight, Thermal
19	1118894	Rocker Arm (2) Switch
20	2195657	Wire Assembly, Freezer Compartment
21	2176281	Cover, Air Diffuser
22	2193455	Knob, Thermostat
23	2182340	Air Tower
24	2176280	Air Diffuser, Bottom
25	2190590	Freezer Floor
26	2179877	Air Diffuser, Top (Includes Item 37)
27	2190688	Cover, Hole
28	941839	Hole Plug
29	2163827	Bracket, Fan Motor
30	2189267	Gasket, Evaporator Cover (Top)
31	2174629	Air Return & Foil Assembly
32	487996	Cap
33	489478	Screw
34	2176297	Knob, Damper
35	2169193	Shroud, Light
36	2172532	Seal, Rear Thermostat
37	2179712	Sleeve
38	2190519	Shield
39	2182382	Housing Base
41	2193096	Wiring Harness, Freezer Light
42	2193491	Electrical Shield, Freezer Light
43	851682	Light Bulb
44	2179859	Post, Damper
45	2163810	Bracket, Damper Knob
48	2166284	Gasket, Rear
49	2195483	Pullout, Freezer Floor (Includes Item 56)
50	2176242	Rear Fence, Pull- Out Freezer Floor
51	2176246	Roller, Slide
52	2179713	Side Support, Floor Assembly
53	2179714	Center Support, Floor Assembly
54	2179720	Trim, Pullout Freezer Floor
56	2179772	Insulation, Freezer Floor
59	2171931	Valve, Release

SHELF PARTS

For Models: 3XARG477GF00

(White)



1	2163756	Shelf, Ladder (2)
2	2163826	Shelf, Ladder Center
3	2163762	Cup, Shelf Mounting
4	2169933	Egg Bin
5	489415	Screw
6	520965	Screw, Support
7	2174446	Frame Assembly, Shelf
9	2195342	Crisper Cover
11	2169921	Glass, Crisper Cover
12	2179716	Frame Assembly, Meat Shelf
13	2172683	Gasket, Crisper Cover
15	2172541	Crisper, Support
16	2176240	Track Assembly, Shelf
17	2176275	Shelf, Freezer
18	2169608	Hook, Shelf
19	2193247	Pan, Crisper Wide
20	2193256	Pan, Meat
21	489419	Screw
22	2195349	Shelf Assembly, Spillguard L/A
23	2176222	Slide, Crisper
24	2163835	Crisper Track, Center
25	2193245	Pan, Crisper
26	2176223	Body, Humidity Control
27	2195340	Trim, Crisper Pan
28	2195341	Trim, Crisper Pan
29	2176356	Trim, Meat Pan
30	2195500	Shelf Assembly, Spillguard (2)
31	841180	Ice Cube Tray
32	489478	Screw
33	2172569	Shelf, Ice Tray
100	2197523	FeaturePak (Includes 4,7,12, 16,18,20,21,22,44,45) Also See Ref.& Frz. Door Pages.

REFRIGERATOR DOOR PARTS

For Models: 3XARG477GF00

(White)



1	2183864	Refrigerator Door (Includes #6 & #8)
3	2183124	Shim, Handle
4	2189202	Bracket, Door Stop
5	488921	Screw, 8 x 1/2
6	2183003	Thimble
7	844478	Hole Plug
8		Door Gasket, Magnetic
	2159057	Mist Beige
9	2151813	Shim, Handle
11	2156062	Housing Compartment
13	2195388	Tray, Door
16	489006	Screw
17	487909	Screw
18	2179398	Shim, Handle
19	2183808	Handle
20	2179605	Bin, Door Shelf (4)
21	2177260	Trim, Door Shelf
22	2182400	Door Compartment
23	2159312	Trim-Door Shelf
24	2189000	Hole Plug, Handle
27	2174006	Cover, Endcap
38	2177340	Endcap, Door Trim
39	2156006	Plug-Trim
100	2197523	Featurepak (Includes 11,13, 20,21,22,23,38,39) Also See Frz.Dr. & Shelf Parts Pgs.

UNIT PARTS

For Models: 3XARG477GF00
(White)



1	2195273	Plate, Unit Mounting
2	2182381	Defrost Bimetal
3	2195400	Condenser
4	2166657	Heater, Defrost
5	2195391	Evaporator Assy.
6	489494	Screw
7	2172619	Drain Pan
8	2176301	Bracket, Heater
9	489478	Screw
10	2163780	Extension, Air Baffle
12	2162358	Cover (Service Only)
13	2169411	Overload (Includes Relay)
14		Grommet (4)
	2183042	Production
	1100826	Service
15		Relay (See Overload)
16	2176302	Support Block
17	836054	Roller (2)
18	2179826	Rivet
19	2182338	Clip, Heater
20	489473	Screw
21	2198740	Cover, Unit
22	2166683	Clip
23	489435	Clip, Wire
28	2169448	Compressor (Includes Items 11,12,13,15,29, 32, 38 & 56) (Also Order
	482801	Installation Kit
	876765	Tube Kit)
29	2174865	Drier
30	2155774	Clamp
32	2154718	Capacitor
38	2172890	Wire Assembly
39	2198921	Air Baffle
40	2198746	Motor, Condenser
42	2195489	Wire Assy. Unit
43	2190685	Fan Blade
44	486692	Nut
46	2179856	Tube, Discharge
47	2179854	Tube, Suction
48	2154109	Tube, Process
49	2174670	Tube, Condenser To Heat Loop
56	487240	Screw
58	2163795	Evap. Tray

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")
482278	Start Kit

REFRIGERANT CHARGE 4.0 Ozs. (R134A)

FREEZER DOOR PARTS

For Models: 3XARG477GF00

(White)



1	2183860	Freezer Door (Includes #6 & #8)
4	2189202	Bracket, Door Stop
5	488921	Screw
6	2183003	Thimble
7	844478	Hole Plug
8		Door Gasket, Magnetic
	2159327	Mist Beige
14	2151813	Shim, Handle
15	1123293	Divider, Door Shelf
16	489006	Screw
17	2171282	Trim, Door Shelf (2)
18	2195061	Nameplate
19	2183811	Handle
20	2174433	Hole Plug
22	2195916	EndCap, Trim (4)
100	2197523	FeaturePak (Includes 15, 17, 22) Also See Ref.Dr. & Frz.Dr. Pgs.

Parts Not Illustrated and Optional Parts (Not Included)

Miscellaneous

978941	Insulation, Fiberglass (63-1/2" x 35-1/2" x 2-5/8")
212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4" x 108")
876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")
876370	Kit, Insulation (2 Pcs. 3" x 24 " x 48")
876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")
505587	Sealer, Mastic (1 Qt.)
511873	Touch-Up, White Porcelain (2 Oz.)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1-1/4 Oz.)
606755	Bag, Insulation (36-5/8" x 46")
799833	Kit, Evaporator Repair (Aluminum Epoxy)
799832	Kit, Porcelain Repair (White)
503695	Cork Sealer (1/4 Pound)
2176379	Door Reversal Instructions

Customer Touch-Up Material

350942	*Primer, White (13 Oz. Spray Can)
350939	*Enamel, Black (13 Oz. Spray Can)
350930	*Enamel, White (13 Oz. Spray Can)
350956	*Enamel, Almond (13 Oz. Spray Can)
72017	Brush Touch-Up Kit (White)
72032	Brush Touch-Up Kit (Black)
72107	Brush Touch-Up Kit (Almond)

Refinishing Material

799344	Enamel, White (1 Qt. Uncut)
978883	Enamel, Almond (1 Qt. Uncut)
833938	Kit, Terminal Connector

*CAUTION: The spray paint is not to be used where the paint may make contact with the door gaskets.

LITERATURE PARTS

LIT2193093	Wiring Diagram
LIT2195605	Energy Label

LIT2195468 Use & Care Guide

Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
LIT677969 Do-It-Yourself Manual Ref./Fzr.
LIT677971 Do-It-Yourself Manual, Icemaker

FIELD INSTALLABLE ICE MAKER ECKMF94

TORX SCREW WRENCH
1117510 Torx Key